



Taking care of your Rug



1. Machine-wash the rug in cold water with the patterned side facing outward. Do not use detergents containing bleach.



2. We strongly recommend hanging the rug outside to dry. (The rug dries quickly.) If hanging is not possible, dry on low heat. Do not use fabric softeners.




3. Vacuum on the lowest setting and avoid using industrial vacuums with brushes. Be careful not to vacuum the edges of the rug.



4. Use a damp cloth with soapy water for spot cleaning. Dry the pad by rubbing it with a towel.



5. Do not machine-wash the rug pad and its grippers. Instead, hand-wash them and hang them outside to dry.



6. Remove the rug from the rug pad before washing. (The rug pad grippers do not need to be removed.) Make sure the grippers do not go into the washing machine. If the grippers lose their stickiness, simply rinse them with water and place them outside to dry before reusing them.


FlexiSpot

Washable Rug






Assembling your Rug



1. Determine where you want to place the rug and clean the area thoroughly.



2. Position each piece of the rug pad according to the details on the next page.



3. Insert the individually packaged grippers into the holes in all four corners of the rug pad.



4. Lay the rug on top of the pad and smooth out any wrinkles.



5. Press down on all four corners of the rug to ensure the grippers and the rug are stuck together firmly.



6. If needed, use additional grippers to secure the corners or edges of the rug (to prevent curling, for example).






Assembling your rug pad


1. Check the size of the rug you purchased.

2. Assembling the rug pad according to the installation diagram below.


① 2.5×7 ft ② 2.5×10 ft ③ 4×6 ft




④ 5×7 ft



⑤ 6×9 ft



⑥ 8×10 ft



⑦ 9×12 ft

