


Item No.XS1O-A/XS1T-A
User Manual



+1 (855) 585-5618





Component List

• SCREW ACCESSORIES




• PARTS ACCESSORIES




TIPS: Some accessories are placed under the seat.


1 Take Recliner Out




2 Expand Recliner




3 Install Armrest



4 Install Seat



6




1. Raise the chair from its initial state (back upright, footrest closed).
2. Press and hold the up or down button, and the chair will rise and fall until the button is released.
3. During use, pay attention to anti pinch measures.

Cautions

1. Children should use the sofa under adult supervision to avoid accidents.
2. Please pay attention to whether there are pets, children, or obstacles in front and behind the sofa when using it.

5 Install Backrest & Connect Cables



Usage

