


Item No.XS1O-A+B+C/XS1T-A+B+C
User Manual




+1 (855) 585-5618




Component List


• SCREW ACCESSORIES



• PARTS ACCESSORIES




3-Seat Sofa




TIPS: Some accessories are placed under the seat.

1 Take Recliner Out




2 Install Armrest





3 Install Seat


Do not tighten zhe screws.




4 Connecting Seats



5 Install Backrest & Connect Cables



6



1. Raise the chair from its initial state (back upright, footrest closed).
2. Press and hold the up or down button, and the chair will rise and fall until the button is released.
3. During use, pay attention to anti pinch measures.

Cautions

1. Children should use the sofa under adult supervision to avoid accidents.
2. Please pay attention to whether there are pets, children, or obstacles in front and behind the sofa when using it.

Usage

