


FlexiSpot

AirBloom Air Purifier

Item No. Y2



Website: www.flexispot.com
Tel: 1-855-585-5618
EPA Est No. : 101594-CHN-1

IMPORTANT SAFEGUARDS

READ ALL INSTRUCTIONS and WARNINGS:

The failure to follow any of the important safe guards, warnings, or instructions for safe use is a misuse of the Y2 Air Purifier that can void your warranty and create the risk of serious injury. When using the Y2, basic safety precautions should always be followed.

1. ONLY use the Y2 for its intended purpose.
2. To protect against the risk of electrical shock, DO NOT immerse the cord, plug, or any part of the Y2 in water or any other liquid.
3. Close supervision is necessary when the Y2 is used by or near children. The Y2 is not intended for use by children, persons with reduced physical, sensory, or mental capabilities, or those who lack expertise or knowledge of this device.
4. DO NOT operate the Y2 with a damaged cord, plug, after any malfunction, or if the unit has been dropped or damaged in any way. Contact Customer Service at 1-855-585-5618 or email contact@flexispot.com for more information.
5. Discard the protective plastic covering the power plug before use.
6. DO NOT run the cord under carpeting. DO NOT cover the cord with throw rugs, runners, or other coverings.
7. DO NOT route the cord under furniture or appliances. Arrange the cord away from high-traffic areas where it will not pose a tripping hazard.
8. Remove any dust or water from the plug, if needed.
9. ALWAYS set up the Y2 on a flat, stable surface.
10. DO NOT set up the Y2 where it could be pushed, kicked, or tripped over.
11. Leave at least 2-3 feet of space between the Y2's vents and any walls.
12. DO NOT install the Y2 near a heating device, flammable or combustible gases or vapors, or in areas exposed to moisture or water.
13. DO NOT place objects on top of the Y2.

14. DO NOT sit or stand on, or lean against, the Y2.
15. Alteration or modification of any part of the Y2, or the use of attachments not recommended by the manufacturer, may cause fire, injury, or damage to property.
16. As with most electrical units, electrical parts are live even when the Y2 is off. Be sure the Y2 is unplugged when assembling.
17. DO NOT use the Y2 in a factory or industrial setting where machine oil may be present in the air.
18. Unplug the Y2 from outlet when the unit is not in use or will be left unattended for an extended period of time; before putting on or taking off parts; when removing or replacing the filters; and before cleaning.
19. DO NOT operate the Y2 if an abnormal sound or motion is detected.
20. If a hard or foreign object comes into contact with the fan, do not operate. Turn off and unplug the Y2.
21. Inspect the Y2 for any loose or missing parts before and after each use. If parts are loose, damaged, or missing, contact Customer Service at 1-855-585-5618 or email contact@flexispot.com.
22. DO NOT block the air inlet or outlet vents.
23. DO NOT operate the Y2 without filters or the Prefilter Access Panel in place.

FILTER CHANGING PRECAUTIONS

1. DO NOT try to clean the HEPA/Carbon filters. Doing so will release dust and other pollutants back into the air. The mesh Prefilter may be washed in warm, soapy water, but must be dried before being reinstalled.
2. ALWAYS use rubber gloves when handling the filters.
3. When removing dirty filters, ALWAYS do so outside or in a well ventilated area.
4. ALWAYS replace your filters with FlexiSpot filters made for your model of air purifier.

REPAIR TIPS

Only the personnel trained and qualified maintenance for air purifier can repair the device.

Other personnel are not allowed to repair the air purifier without permission, so as to avoid serious consequences.

When the air purifier is abnormal, please refer to the Common Troubleshooting Methods.

If you can't troubleshoot the fault, please unplug the wire and cut off the power, then contact us. Any product quality or inconvenience caused by the device can be obtained from the local merchant customer service center or consultation and services.

Please read this user manual carefully to ensure correct and safe use of this product.

ONE KEY THING TO REMEMBER

ALWAYS remove the plastic wrapping from new filters BEFORE using them in the Y2.

Failing to do so may damage the motor and other parts of the Y2 and may void your warranty.

For the removal and installation method of the filter, please refer to "Filter Installation Procedure".


Specification

Item No.	Y2
Rated Voltage	120V~
Rated Frequency	50-60Hz
Rated Power	34W
Clean Air Delivery Rate (CADR)	250m³/h
Product Dimensions	8.7"D x 8.7"W x 12.6"H
Suitable Area	210 square feet
Compliance Standards	FCC, RoHS, EPA

Package List

Name	Air Purifier	Pre-filter & HEPA & Carbon Triple Layer Filter	Manual
Quantity	1	2	1

Products and Accessories



Accessories List

1	Prefilter Access Panel	7	Power Adapter
2	HEPA/Carbon Filters	8	Front Panel
3	Left Volute Housing Assembly	9	Motor
4	Rear Panel	10	Fan Impeller
5	Air Outlet Grid	11	Bottom Cover
6	Particulate Matter Sensor	12	Right Volute Housing Assembly

Filter Installation Procedure



Figure1



Figure2




Figure3




Figure4




Figure5

Warning

When handling the packaging materials, do not use sharp objects such as knives to cut open plastic bags and films to avoid damaging the product.

Before using, you need to make sure that the filters are properly installed. With the Y2 unplugged:

1. As shown in Figure 1, remove the Prefilter Access Panels from both sides of the machine.
2. As shown in Figure 2, take out the composite HEPA/Carbon Filters from their slots.
3. As shown in Figure 3, remove the plastic wrapping from the new filters.*
4. As shown in Figure 4, fully insert the HEPA/Carbon Filters into their slots and reinstall them into the machine, ensuring that the carbon side is facing inward.
5. As shown in Figure 5, reattach the Prefilter Access Panels to the machine, making sure that each is secure.
6. Remove the sticker from the control panel.*


**When using the Y2 Air Purifier for the first time.*




Note




Before replacing the filter, please ensure that the power is disconnected and follow these steps strictly!

Control Panel



Button Function Descriptions


Button Icon	Function	Operational Description	Remarks
 Power / Standby	Power On / Power Off	In standby mode, a light touch of the power button will start the machine, which will then enter the working state with the default mode set to Auto mode. In the working state, a light touch of the power button will shut down the machine, which will then return to standby mode.	<ul style="list-style-type: none"> Upon powering on, a "beep" signals all lights to illuminate for 2 seconds before going out, entering standby mode. In standby, the power button light flashes red, then changes to a dim white light after 5 flashes (other lights off). In operation mode, the indicator light will be illuminated with a white light. After powering on, the PM2.5 value will display 0 for 2 seconds.

 Mode	Switch Modes	In the working state, a light touch of the mode button will cycle through the available modes, which can be identified by the mode indicator light. The selection order is Auto mode, Sleep mode, Turbo (or High Power) mode, and then back to Auto mode.	<ul style="list-style-type: none"> After turning on the machine, it defaults to Auto mode. In Auto mode, the machine automatically adjusts the fan speed in real-time based on the air quality level, providing intelligent control. In Sleep mode, the machine operates at an ultra-quiet fan speed. After 5 seconds of inactivity, all button indicator lights will turn off, and the display will go dark except for a faint status indicator light. Touching the button area will reactivate the display. In Turbo mode, the machine operates at the maximum fan speed.
 Timer	Set Timer Duration / Long Press for Mute	<ul style="list-style-type: none"> In the working state, a light touch of the timer button will cycle through the available timer settings, which are: No Timer - 1 Hour - 2 Hours - 4 Hours - 8 Hours - No Timer. During operation, press and hold the timer button for 2 seconds to mute the buzzer, which will confirm with two beeps (BB). To re-enable the buzzer sound, press and hold the timer button for another 2 seconds, which will also be confirmed by two beeps (BB). 	<ul style="list-style-type: none"> When the timer is set, the timer button indicator light will be fully illuminated; otherwise, it will be at half brightness. When selecting 1H (1 Hour), 2H (2 Hours), 4H (4 Hours), or 8H (8 Hours), the corresponding indicator light will illuminate sequentially. The buzzer sound setting is retained even after power loss (i.e., it has a "latch" memory), and upon new power-up, it retains the sound state from before.
 Filter Reset (Press and hold for 3 seconds)	Reset Filter Life Indicator	When the cumulative working hours reach 6,480 hours (approximately 9 months), the indicator light will illuminate. To reset the filter life timer, press the Filter Reset button. The filter life timer will be reset to zero and the indicator light will turn off after the reset. (The Reset button will not respond to presses under normal circumstances and will only react when the timer reaches the point where the indicator light is illuminated and then the reset button is pressed.)	<ul style="list-style-type: none"> The need to replace the filter can be determined by the filter maintenance indicator light. It is recommended to perform a filter life reset after replacing the filter.

*Note:

- Upon successful completion of any operation, the machine's buzzer will emit a single 'beep' sound as confirmation.
- If there is no operation within 3 minutes while the machine is in the working state, the brightness of all displays will be reduced to save energy. The brightness will return to normal once any button is pressed.
- In Sleep mode, when all the button lights in the control area are turned off, you can activate the button lights by touching the control area, after which you may perform button operations.

Screen Display Description




Indicator Function Descriptions


Indicator	Indicator Description	Remarks
PM2.5 Index Indicator	In the working state, the air purifier displays the real-time PM2.5 index of the environment, measured in micrograms per cubic meter ($\mu\text{g}/\text{m}^3$). The display range is from 1 to 999. If the value exceeds 999, it will be displayed as 999.	<ul style="list-style-type: none">• Within the first 2 seconds after power-on, the PM2.5 index will be displayed as 0.• It takes approximately 10 seconds after power-on for the PM2.5 index display to stabilize.• In Sleep mode, the PM2.5 index display will be turned off after 5 seconds of inactivity without any operation.

Work Mode Indicator	In the working state, the corresponding work mode indicator light will illuminate based on the current operational mode, while the indicator lights for non-active modes will be turned off.	<ul style="list-style-type: none">• Sleep Mode: The machine operates in an ultra-quiet state, with all button and display area lights turned off, except for the status indicator light.• Auto Mode: In Auto mode, the machine can simultaneously detect PM2.5, PM10. If any of these readings are abnormal, the machine will activate and automatically adjust the operating power based on the current air quality level.• Turbo Mode: The machine operates at its maximum power output.												
Filter Maintenance Indicator	When the cumulative operating time reaches 6,480 hours (approximately 9 months), the indicator light will illuminate, signaling that the filter's life has expired. To reset the filter life timer, press and hold the Filter Reset button for more than 3 seconds. The filter life timer will reset to zero and the indicator light will turn off after the reset.	<ul style="list-style-type: none">• The Reset button is inactive under normal circumstances and will only respond when the timer reaches the point where the indicator light is illuminated and then the reset button is pressed.												
Air Quality Level Indicator	The air purifier displays the air quality level based on the dust particle count, with the following color and auto mode fan speed settings: <table><tr><th>Index ($\mu\text{g}/\text{m}^3$)</th><th>Color</th><th>Auto Mode Fan Speed</th></tr><tr><td>0-35</td><td>Blue</td><td>700 RPM</td></tr><tr><td>36-120</td><td>Yellow</td><td>1100 RPM</td></tr><tr><td>≥ 120</td><td>Red</td><td>1380 RPM</td></tr></table>	Index ($\mu\text{g}/\text{m}^3$)	Color	Auto Mode Fan Speed	0-35	Blue	700 RPM	36-120	Yellow	1100 RPM	≥ 120	Red	1380 RPM	<ul style="list-style-type: none">• In Sleep mode, the air quality level indicator will be turned off after 5 seconds of inactivity without any operation.
Index ($\mu\text{g}/\text{m}^3$)	Color	Auto Mode Fan Speed												
0-35	Blue	700 RPM												
36-120	Yellow	1100 RPM												
≥ 120	Red	1380 RPM												

Placement and Adapter Information



To ensure optimal air purification effectiveness, please ensure that the machine is kept at a minimum distance from any obstacles as indicated in the figure (over 1 inch is the minimum, with 2-3 inches being optimal).



Connect the adapter's power cord to the DC socket on the back of the machine, and then plug it into a power source.

Common Troubleshooting Methods

When encountering the following common issues, users can perform self-troubleshooting.



Attention: If you detect a problem, please switch off the machine immediately to prevent damage to the unit and to avoid any potential hazards.

Problems	Checklist	Solutions
The Y2 does not turn on	Check if the power outlet is providing electricity	Ensure the power outlet is active and has electricity
	Check if the power plug is properly connected	Ensure the power plug is securely connected to the outlet and the machine
Odor from the air outlet grid	The filter screen is severely contaminated (Expiration)	Replace with an original FlexiSpot filter
The machine is running normally but the indicator light is off	Indicator light failure	Contact customer service for repair assistance
Reduced air output / Purification effect is not significant	Verify if the filter has reached the replacement time	Clean or replace the filter screen
	Check for any obstructions at the air outlet	Turn off the machine and remove blockages or change places
Abnormal motor	Motor rotation blockage / motor overheating protection; Machine prompts and does not work	Unplug the power and cool for 1-2 hours, then reconnect the power supply; If the issue persists after above steps please contact the after-sales service center



Note

If the issue is not resolved after performing the above checks, please contact the service center or technical support center provided by our company's customer service. Do not attempt to disassemble or repair the unit yourself to avoid potential hazards and damage to the machine. If the power adapter is found to be damaged, for safety reasons, it must be replaced by a professional from the manufacturer, its service department, or a similar qualified service.

Maintenance and Care



Note

Please turn off the power and unplug the power cord before performing any maintenance or care procedures.

1. Cleaning Frequency and Precautions

- The cleaning frequency of the product's exterior should be determined by the user based on the actual usage environment.
- Always unplug the power cord and wait for at least 10 seconds before cleaning or performing maintenance to avoid working with electricity.
- The exterior of the product can be wiped clean with a dry cloth. Do not use a stiff brush to clean the surface to prevent scratches.
- Since the product contains high-voltage components, do not wipe the top outlet with a wet cloth to avoid causing an internal short circuit that could damage the product.
- As the product contains high-voltage components, it is strictly prohibited to use flammable substances (such as alcohol, gasoline, paint, thinners, and banana oil) to clean the exterior, internal circuit components, or any other parts of the machine.

2. Filter Replacement

- When the filter maintenance indicator light illuminates, indicating that the filter's lifespan has expired, stop using the product and replace the filter promptly.
- Refer to the 'Filter Installation Procedure' page for illustrations and written descriptions on how to replace the filter.
- After replacing the filter, reset the filter timer as described on the 'Function Descriptions' page.
- Please use filters and other consumables provided by FlexiSpot. Using filters not provided by the original manufacturer may result in the product's filtration and sterilization functions not meeting standards or becoming ineffective. In severe cases, it may cause irreversible damage such as motor burnout.

FlexiSpot Limited Warranty

This limited warranty offered by FlexiSpot covers defects in material or workmanship in new FlexiSpot products. This warranty extends to the original purchaser only and is non-transferable. Only consumers purchasing FlexiSpot products from authorized FlexiSpot retailers or resellers may benefit from our limited warranty.

What is Covered?

FlexiSpot AirBloom Air Purifier

All AirBloom air purifiers in the Y2 and Y4 series feature a 2-year warranty and a 30-day hassle-free return and exchange policy.

What are your Remedies?

FlexiSpot will replace at no charge to the consumer the defective parts only or, at FlexiSpot's option, replace any product or part of the product that is defective because of improper workmanship and/or material, under normal installation, use, service and maintenance. If FlexiSpot is unable to provide a replacement and repair is not practical or cannot be completed in a timely fashion, FlexiSpot may elect to refund the purchase price in exchange for the return of the product. In the rare event that your FlexiSpot product is defective, we will provide you with a replacement item shipped at no cost to you within the continental United States. The shipping method for replacement products is FedEx Ground, but expedited shipping is available if you choose to pay the additional expense. In addition, you will need to pay the shipping costs if any products need to be shipped to you at an address outside the continental United States. REPAIR OR REPLACEMENT (OR, IN LIMITED CIRCUMSTANCES, REFUND OF THE PURCHASE PRICE) AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE PURCHASER. FLEXISPOT NEITHER ASSUMES NOR AUTHORIZES ANY PERSON TO CREATE FOR ANY OTHER OBLIGATION OR LIABILITY IN CONNECTION WITH THIS PRODUCT.

What is Not Covered?

Our limited warranty does not cover any problem that is caused by:

1. Conditions, malfunctions or damage not resulting from defects in material or workmanship.
2. Conditions, malfunctions or damage resulting from normal wear and tear, improper installation, improper maintenance, misuse, abuse, negligence, accident or alteration.
3. Accessories, connected materials and products, or related products not manufactured by FlexiSpot.
4. Conditions, malfunctions or damage resulting from failure to follow the instructions and guidelines relating to the product's intended use.

Our limited warranty is void if a product is returned with removed, damaged or tampered labels or any alterations (including removal of any component or external cover).

FlexiSpot Limited Warranty

How to File a Claim?

In order to receive the benefit of our limited warranty, you need to process your claim in compliance with the terms of this limited warranty and follow proper return procedure. To request warranty service, please contact customer service via email at contact@FlexiSpot.com or toll free at 1-855-585-5618. You will need to provide the sales receipt or other evidence of the date and place of purchase for your FlexiSpot product.

Implied Warranties and Limitation of Damages

EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ALL IMPLIED WARRANTIES (INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE) SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY, AND FLEXISPOT SHALL NOT BE LIABLE FOR ANY INCIDENTAL, INDIRECT, SPECIAL, OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO LOSS OF PROFITS OR REVENUE, RESULTING FROM ANY BREACH OF EXPRESS OR IMPLIED WARRANTY OR CONDITION, OR UNDER ANY OTHER LEGAL THEORY, EVEN IF FLEXISPOT HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Some jurisdictions do not allow limitations on the duration of an implied warranty or the exclusion or limitation of special, indirect, incidental or consequential damages, so the above limitations or exclusions may not apply to you.

Governing Law

This Warranty shall be governed by the laws of the State of California, USA, without giving effect to any conflict of laws principles that may provide the application of the law of another jurisdiction.

How State Law Applies

This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state.