


FlexiSpot

Item No. XL2

User Manual








+1 (855) 585-5618



Component List

* NOTE:

Some accessories are placed under the base of the recliner. Please take out the wings of the backrest and the inner spring cushion to ensure proper installation.

A 	B 	C 
Backrest x1	Seat x1	Inner Spring Cushion x1
D 	E 	F 
Backrest Wings x2	Armrest Foam x2	Massage Function Remote Control x1
G 	H 	I 
Backrest and Footrest Remote Control x1	Power Transformer x1	Power Transformer Cord x1




CAUTION: At least two adults are required to safely assemble this recliner safely. As some parts are large and heavy, you might risk hurting yourself if you attempt to lift the parts on your own.

1

Take Recliner Out

1. Turn the box upside down.
2. Cut the cable ties.
3. Remove the recliner from the box.

TIPS: It is recommended to lift the box up from the bottom to slide the recliner out of the box.




2

Expand Armrest


Left armrest

Pull with both hands.



Right armrest

Pull with both hands.




* NOTE:

Hold the handles of each armrest with both hands and pull it out horizontally until you hear two clicks, which means that the armrest is extended.

3

Install Seat Cushion


Insert the inner spring cushion **C** into the seat **B**.
* **NOTE:** The inner spring cushion is vacuum-packed. Remove it from its plastic bag.



4



Install Armrest Foam

Insert the armrest foam **E** into the armrest pads of the seat **B**.




5

Install Backrest




***Tips:** First, install the backrest. Then, fasten it to the seat using the Velcro tape.





6

Connect Cables





Open the cover behind the backrest. Then, connect the cables.

Refer to the diagrams to connect the cables.



AREA B


Connect the cables of the same color under the backrest and the seat. Connect **F** to cable under on the backrest.



Connecting the cables:


1. Connect the cables as shown above. Some of the connectors have guide pins to help with alignment.
2. Fasten the cable locks and make sure they are locked in place. This prevents the cables from being pulled out accidentally.

Reattach the cover behind the backrest. The assembly of the XL2 is complete.



Operating the Recliner


Adjusting the Backrest and Footrest



1. Power on the recliner: Plug the power cord into a power source.
2. Recline the backrest and raise the footrest: Press the Recline and Footrest button to recline and raise the footrest to your desired position.
3. Press the Reset button once to restore the recliner to its default position.



Note:

Do not place objects under the recliner and its footrest when the recliner is fully reclined. Keep young children and pets away from the recliner while it is being operated.



Backrest and Footrest Remote Control

Lifting and Lowering the Recliner



Backrest and Footrest Remote Control

1. Lift the recliner while it is in its default position, where the backrest is upright and the footrest is folded.


2. Long press the Lift button until the recliner reaches your desired angle.

3. Press the Reset button to lower the recliner.

Using the Massage Function

INTENSITY: Adjust the massage intensity (High, Middle, Low).

HEAT: Turn on/off the heat for the lumbar area.



POWER: Turn on/off remote control.



TIMER: Set the massage duration for 10, 20, or 30 minutes.

MODE: Choose from 5 massage modes ranging from M1 to M5.

AREA: Select your desired massage area (Back, Lumbar, Thighs, Legs, Full Body). Press on the PART button twice to save the current setting.

We recommend using the massage function for a few minutes initially to allow your body to get used to the massage sensation. Over time, increase the massage duration gradually. If you experience any discomfort, stop using the massage function immediately and consult your medical practitioner.

Retracting the Armrests




Using the Recliner Properly






- How to stand up from your recliner safely**
1. Store the Massage Function Remote Control **F** and the Backrest and Footrest Remote Control **G** in the recliner's side pocket.
 2. Plant your feet firmly on the floor.
 3. Distribute your weight evenly across both legs.
 4. Stand up slowly.

*Remember to store the Massage Function Remote Control **F** and the Backrest and Footrest Remote Control **G** in the recliner's side pocket when not in use.

*The recliner's upholstery will fade under direct exposure to sunlight. To extend the life of your recliner, minimize its exposure to sunlight.




Warning




To ensure that you can recline the backrest, the recliner should be placed at least 17.7" away from the wall.

Handle the recliner and its accessories with care.




Only move the recliner when it is in its default position. Never attempt to move the recliner when it is reclined. Always use the armrest handles to move the recliner. Do not move the backrest or its wings.



DO NOT stand up when the footrest is in the upright position.

DO NOT stand up from your recliner with unevenly distributed weight.



DO NOT stand up from your recliner with only one arm pressed against the recliner.

Maintenance and Care Methods

- To maintain the recliner's quality, it is recommended to position it at a minimum distance of 30cm from direct exposure to sunlight. Every 10-15 days, it is advisable to utilize a vacuum cleaner to eliminate dust and other particles, ensuring a thorough cleanliness of the recliner.
- To ensure the everlasting smooth quality of the fabric, it is crucial to promptly address any stains before resorting to scraping or employing other destructive treatments. A protective cover can be placed over the recliner surface as a preventive measure. In case of ink stains, using a gentle white cloth or absorbent paper to carefully wipe them away will effectively remove any residue.
- If you need to use solvent to remove stains, please avoid applying it directly onto the stained area. Instead, pour the solvent onto a clean cloth and then use the cloth to gently blot the stains. To ensure safety, it is recommended to perform a cleaning test on a hidden area at the back before treating the stains. When treating the stains, start wiping them in a circular motion from the outside towards the center, until the stains are completely removed. Finally, immediately after wiping, use a low-power hair dryer to gradually dry the area, starting from the outer edges and moving towards the center.
- When wiping stains, it is important to be gentle and exercise caution, avoiding applying excessive force. To protect your recliner, you can consider using a removable and close-fitting protective cover.
- If you have adorned your sofa with a close-fitting protective cover, clean it by following the guidelines mentioned on the cover using an oxidizer lotion free from bleach. Neglecting to do so may result in an alteration of the texture and hue of the recliner's fabric.

• Regular Vacuuming

Make it a habit to vacuum your recliner at least once a week, giving special attention to the corners where dust tends to accumulate. In case you notice any stains, gently wipe them with a clean cloth dampened in water to prevent leaving behind any marks. For best results, begin wiping from the outer edges of the stain towards the center.

• Effective Cleaning Methods

To clean effectively, start by using warm distilled water to eliminate fat and acid contamination. Moisten a clean cleaning cloth and scrub from seam to seam. For stains that contain protein, such as blood or urine, it is recommended to use ice water. Dry stains usually require scrubbing with a pH neutral soap or thymol. Dilute the foam and apply it to the stain, and if you are dealing with a large area, wash from the outside towards the inside. Afterward, use a clean cloth and diluted distilled water to wipe the surface. To get rid of any remaining moisture, use a dry cloth. In case you come across difficult stains like blood, gum, or ballpoint pen marks, it is advisable to seek professional help or ask for advice on the best method to remove them.

• How to remove stubborn stains

If there is gum or other glue on the recliner, you can use an ice pack or ice water to cool down and then gently wipe off with a fine cloth.

Product Precautions

1. Unpacking and Checking

- Prior to opening the package, it is advisable to examine the package for any signs of damage or tampering. Once unpacked, carefully inspect the product's external condition for any dents, scratches, or other potential issues. Subsequently, ensure that all accompanying accessories are present and accounted for. Avoid utilizing sharp tools during the unpacking process to prevent any unintended harm or damage to the recliner's surface;
- After the product undergoes prolonged transportation over long distances, it is expected that temporary indentations may form. However, it is natural for these indentations to gradually recover after the product is used for a certain period of time.

2. Transportation and Storage

- Before relocating furniture, it is crucial to ensure that items are removed to avoid any potential harm caused by falling components during the furniture moving process. This precautionary measure is vital to ensure the safety of individuals involved.;
- When it comes to relocating furniture, it is essential to lift it carefully and place it in an appropriate position before gently lowering it. During the moving process, it is advisable to refrain from pulling or exerting excessive force to prevent any potential damage, such as loosening or breaking the iron frame and internal structure;
- When you relocate your furniture, it is crucial to ensure that its base is securely grounded in its new position.;
- When disassembled furniture needs to be moved, take it apart and move it.
- When furniture remains idle for an extended duration, it is advisable to shield it using packing materials that are impervious to dust and light. Furthermore, it should be securely positioned within an indoor space that ensures adequate dryness and ventilation.

3. In Use

- Before using furniture, it is important to ensure that it is perfectly levelled.
- It is advisable to refrain from prolonged exposure to sunlight and high-energy lamps, as they can lead to local discoloration or fading.
- Avoid placing any heavy items on the non-load-bearing components of the furniture.
- Connectors, if loose, should be locked in time, prohibit the use of non-locking state.
- Please keep the room ventilated and with normal dryness and humidity to avoid mould and mildew on the body of the recliner.
- When expanding the recliner, please do not put your hands into the iron frame and internal structure to prevent the possibility of hand injuries or pinches;
- Do not sit alone on the armrests or in front of the unfolded seat;3.8. If not used for a long time, the power needs to be cut off;

4. Maintenance

- Try to avoid standing, jumping or sitting hard on your furniture, as this can cause damage to your furniture. Sharp objects (keys, knives) and animal claws can cause damage to your furniture.
- Power off when using wet cloth for maintenance.